

# REMOTE CONTROL

## How to use the remote control?

### KEYS

#### PARAMETERS

- A** External monitoring / test
- B** IR-detection field
- C** Uncovered zone
- D** Mounting height / Frequency
- F1** Output redirection
- F2** Door control
- Detection field size
- Hold time
- Detection mode
- Radar immunity filter
- Output configuration
- Max. duration of presence detection
- IR-immunity filter




\* not used

#### Laser Scanner

- A** Field dimensions - optional - width
- B** Field dimensions - optional - height
- C** Field dimensions - safety - width
- D** Field dimensions - safety - height
- F1** Detection field redirection
- F2** Uncovered zone
- Object size
- Output activation delay
- Active curtains
- Mounting side
- Output configuration
- Immunity filter

#### VALUES



#### GENERAL KEYS

- Unlock
- Lock
- Check value
- Increase by 1
- Decrease by 1
- Setup / Teach-in  
Factory values  
Presettings

## USE



After unlocking, the red LED flashes and the sensor can be adjusted by remote control.



If the red LED flashes quickly after unlocking, you need to enter an access code from 1 to 4 digits.




To end an adjustment session, always lock the sensor.

### ADJUSTING ONE OR MORE PARAMETERS




### CHECKING A VALUE




X = number of flashes = value of the parameter

### RESTORING TO FACTORY VALUES




\* When no green LED is available, the signal is red.

### SAVING AN ACCESS CODE




The access code (1-4 digits) is recommended to set sensors that are installed close to each other.

### CHANGING AN ACCESS CODE



Enter the existing code

### DELETING AN ACCESS CODE



Enter the existing code

If you forget the access code, proceed as follows:



Unpower & power the sensor

During 1 minute, you can access the sensor without access code

